



# THE SKIMMY HOOK™

1. Connect the top half to the bottom half.



2. Insert screws into the left and right-side holes. {Philips Screwdriver}



3. That's It! You are ready to use  
THE SKIMMY HOOK™

- For swimming pool skimmer basket retrieval ONLY!
- Only use THE SKIMMY HOOK at a swimming pool pump speed of 50% or less.
- **“DO NOT”** use THE SKIMMY HOOK when the swimming pool pump speed is running at 100%!
- Warning: This product contains small parts not suitable for young children.



**⚠ WARNING:**  
CHOKING HAZARD  
Small Parts.  
Not for children under 3 years.

Visit: [www.THESKIMMYHOOK.com](http://www.THESKIMMYHOOK.com)

- Skimmer Basket Lid Removal
- Place hook in one hole only



- Skimmer Basket Removal

